

## Top Hole Install Chart for Stationary Rods

This chart will position the bracket so the drapery will clear the floor approximately ½".

1. Find your Kirsch® product in the left hand column.
2. Select the correct header style.
3. Determine the desired finished drapery length.
4. Add or subtract number in the top hole column from the drapery's finished length to determine how high to measure for the top hole of the bracket.

### Definitions:

Take up – The amount a rod pocket drapery shortens after the rod is inserted into the pocket.

Note: Take up is already calculated in the top hole deduction/addition for rod pocket draperies below.

Top Hole – The top or the highest hole on a Kirsch® bracket.

Pin Set – The position of the pin on a drapery header.

	Rod Pocket (no top ruffle)		Pleated (any variety)	
	Top Hole	Take Up	Top Hole	Pin Set
<b>Buckingham®</b>				
1¾" Pole	- 1 <sup>13</sup> / <sub>16</sub> "	1"	+1 <sup>9</sup> / <sub>16</sub> "	¼"
2" Pole	- 2 <sup>3</sup> / <sub>16</sub> "	1½"	+2 <sup>3</sup> / <sub>8</sub> "	¼"
3" Pole	- 3 <sup>7</sup> / <sub>16</sub> "	2"	+2 <sup>11</sup> / <sub>16</sub> "	¼"
1¾" Pole Transitional	- 1¼"	1"	+2 <sup>3</sup> / <sub>8</sub> "	¼"
2" Pole Transitional	- 1½"	1½"	+2 <sup>9</sup> / <sub>16</sub> "	¼"
3" Pole Transitional	- 1 <sup>7</sup> / <sub>16</sub> "	2"	+4 <sup>1</sup> / <sub>4</sub> "	¼"
<b>Designer Metals™</b>				
1¾" Decorative Wall Bracket	- 9 <sup>1</sup> / <sub>16</sub> "	1"	+1 <sup>7</sup> / <sub>8</sub> "	¼"
1¾" Decorative Double Bracket	- 9 <sup>1</sup> / <sub>16</sub> "	1"	+1 <sup>7</sup> / <sub>8</sub> "	¼"
1¾" Decorative Wall Bypass Bracket	- 9 <sup>1</sup> / <sub>16</sub> "	1"	+1 <sup>7</sup> / <sub>8</sub> "	¼"
1¾" Decorative Double Bypass Bracket	- 9 <sup>1</sup> / <sub>16</sub> "	1"	+1 <sup>7</sup> / <sub>8</sub> "	¼"
1¾" Standard Bracket	- 1¼"	1"	+1 <sup>7</sup> / <sub>8</sub> "	¼"
1¾" Standard Double Bracket	- 1¼"	1"	+1 <sup>3</sup> / <sub>16</sub> "	¼"
1¾" Standard Bypass Bracket	- 1¼"	1"	+1 <sup>1</sup> / <sub>8</sub> "	¼"
<b>Wrought Iron</b>				
1¾" Standard Bracket - 3½" Return	- ⅛"	1"	+3 <sup>1</sup> / <sub>16</sub> "	¼"
1¾" Standard Bracket - 5½" Return	3 <sup>1</sup> / <sub>16</sub> "	1"	+3½"	¼"
1¾" Double Bracket	½"	1"	+3¾"	¼"
1¾" Bypass Bracket	- ⅛"	1"	+3 <sup>1</sup> / <sub>16</sub> "	¼"
1" Standard Bracket - 3½" Return	¼"	¾"	+2½"	¼"
1" Standard Bracket - 5½" Return	5 <sup>1</sup> / <sub>8</sub> "	¾"	+2 <sup>7</sup> / <sub>8</sub> "	¼"
1" Double Bracket	7 <sup>1</sup> / <sub>8</sub> "	¾"	+3 <sup>1</sup> / <sub>8</sub> "	¼"
1" Bypass Bracket	½"	¾"	+2¾"	¼"
<b>Wood Trends™</b>				
1¾" Standard Bracket	- 1 <sup>13</sup> / <sub>16</sub> "	1"	+1 <sup>9</sup> / <sub>16</sub> "	¼"
1¾" Decorative Bracket	- 1¼"	1"	+2 <sup>1</sup> / <sub>8</sub> "	¼"
2" Pole	-2 <sup>3</sup> / <sub>16</sub> "	1½"	+2 <sup>3</sup> / <sub>8</sub> "	¼"
<b>Basic Drapery Hardware</b>				
Undertreatment	n/a	n/a	+1¾"	1½"
Curtain Rod	½"	+1 <sup>1</sup> / <sub>8</sub> "	n/a	n/a